

ATTENTION

Installing XP8, XP9, XP10 with the long part of the pins down

Mounting Example

M1,M2, S1,S2 mount after assembly

DO NOT MOUNT

J1..5

M1..2

S1..2

XP1

XP11

PCB Jumpers install in this positions, not shortcircuit anything, just hold in place

Mechanical Components

Designator	PartType	Quantity	Description	Manufacturer
S1, S2	PCHSS-10	2	PCB standoff M3x10 mm	"Connfly"
M1, M2	M3X5/D7985-A2	2	M3 x 5mm Screw	"KRAFTBERG"
J1, J2, J3, J4, J5	2-881545-2	5	PCB Jumper	"TE Connectivity"

TITLE

=Prj

DESIGNER

EVU-BA-2.5

PRODUCT NUMBER

2.5

SHEET VERSION

d17c61bc [Modified]; 10:33

LAST MODIFIED

SHEET 1 OF 1